




1MORE MUSIC APP





For users outside mainland China, please download the 1MORE MUSIC APP for product upgrades and additional features.


Inside The Box




Headphones × 1 Pair
Charging Case × 1




Silicone Ear Tips × 3 Pairs
(XS / S / L)




Type-C Charging Cable × 1



Carrying Pouch × 1




User Guide × 1




Warranty Card × 1


Product Overview



Replace




Placement



Power

Power On: Open the charging case, the headphones will turn on automatically.


Power Off: Put the headphones back into the charging case and close the lid, they will automatically turn off and start charging.



* Above functions are available for either earbud in individual or Stereo mode.


Headphones Pairing

The headphones will automatically pair to each other after the lid is open while they are in the case.



Bluetooth Pairing To The Device

- To connect to your device during first use, turn the headphones on to enter pairing mode. Headphones will enter the sleep mode if not paired to a device within 3 minutes.
- After the first successful pairing, headphones will automatically connect to your device when the case lid is opened.
- To pair with a new device: put headphones back into the case, click the pairing button for 3 times when powered on (no music or phone calls) to re-enter pairing mode.



* Above functions are available for either earbud in individual or Stereo mode.

Charging Methods

With the Type-C cable, a full charge will take around 2 hours. A green light on the charging case indicates full battery.


With the charging case, a full charge will take around 1 hour. The red lights on the headphones turn off indicating charging is complete.

Battery Status Display in 1MORE MUSIC APP

Battery status of headphones and charging case will be displayed in 1MORE MUSIC APP.

Home


1MORE ComfoBuds Pro True Wireless In-Ear Headphones



Battery Notification


LED indicator for low battery: when there is 25-30 minutes of use left, you will hear the notification sound and the LED indicator will flash in red twice.

When case battery is too low on charge, LED indicator will flash red.




Touch Controls

Phone calls and music can be controlled by tapping on the Touch Control area of the headphone.



Phone Call



Playback

Answer/End call: Double-tap

To activate voice control on cellphones: Tap the controls 3 times when Bluetooth is on and not on a phone call.


Play/Pause: Double-tap

	L	R
Double-tap	Play / Pause >	Play / Pause >
Tap 3 Times	Voice Control >	Voice Control >

* To decline a call, please operate on paired mobile phone.
* To change a song or control volume, please set up on 1MORE MUSIC APP or operate on paired mobile phone or device.

Auto Pause/Play:


Playback will auto pause when it detects the earbuds are removed from the ears, it will auto play when it detects they are on again.



ANC-Strong, ANC-Mild, WNR and Pass-through Modes

- ANC-Strong: suitable for aviation, highspeed train, metro etc.
- ANC-Mild: suitable for noisy daily circumstances, such as malls, cafés, streets etc.
- WNR Mode (Wind Noise Resistance) : Helps attenuate audible wind noise while listening.
- Pass-through Mode: Lets in environmental sounds so you don't need to take out the earbuds to hear what is going on around you.

The default setting of the headphones is:
ANC-Strong/Pass-through (Touch and hold the Touch Control to switch on Left/Right headphone)



Extra Functions

Set up personal listening mode in 1MORE MUSIC APP:

Listening modes

OFF Strong Mild Pass-through WNR

ANC-Mild and WNR are included in 1MORE MUSIC APP, with ANC-Strong together for personal setup.

ANC Modes

ANC Strong ANC Mild

WNR WNR

- If headphones cannot pair normally when they power on. Open the case, and quickly click the pairing button in the case for 3 times to initiate searching for Left & Right pairing modes.
- To unpair the cellphone:
Put both L & R into the case, and then press and hold the pairing button in the case for 8 seconds.
- OTA Firmware Update: can be done synchronously with 1MORE Assistant APP when Left and Right headphones Bluetooth paired to each other.

* Functions of 1MORE MUSIC APP may vary with different cellphones or operating systems. For more details, please contact our customer service.

Model: ES901
Headphone Weight: 5.2 g
Case Weight: 40 g
Product Weight: 50.4 g
Headphone Size: 42 × 23.95 × 20.93 mm
Case Size: 80 × 37.5 × 30 mm
Headphone Battery Capacity: 50 mAh
Case Battery Capacity: 450 mAh
Headphone Charging Time: 1h
Case Charging Time: 2h
Playtime* (ANC On):
Headphone Fully Charged: 6h
Headphones & Case Fully Charged: 20h

Playtime* (ANC Off):
Headphone Fully Charged: 8h
Headphones & Case Fully Charged: 28h
Impedance: 32 Ω
Wireless Range: 10 m
Bluetooth: Bluetooth®5.0
Bluetooth Protocol: HFP / A2DP / AVRCP
Input: 5V=1A
Working Temperature: 0 °C - 45 °C
Frequency Band: 2.400 GHz ~ 2.4835 GHz

The specifications are acquired from laboratory tested data.
* The playback time, tested under the laboratory condition of AAC format and 50% volume, may vary with different device setting, environments, usage and other factors.

Manufacturer: Timlab Acoustic Technology Limited
Address: Tianliao Building 1403, Zone A Tianliao Industrial Park, Taoyuan Str., Nanshan Dist., Shenzhen, P.R. China
Made in China