

# LIFEJACKET XL


## RUGGED BLUETOOTH SPEAKER




**Quick Start Guide**  
Item # IMW789



1. Make sure the following items are included in your package.




2. For a look at the various buttons on your speaker, view the graphic below.




Power On.....Hold for 2 Second  
 Power Off.....Hold for 2 Seconds  
 Play / Pause.....Press   
 Volume Up / Down.....Press + or -  
 Pairing Mode / Disconnect Device...Hold + and -  
 Answer / End Call.....Press   
 Stereo Plus Pairing.....Hold for 2 Seconds  
 Next Track.....Hold +  
 Previous Track.....Hold -

3. Connect one end of the included USB Cable into the Micro USB charging port on your speaker. Plug the other end of the USB Cable into the included AC Adapter. Then plug the AC Adapter into a suitable power outlet in your home in order to charge your speaker's internal battery. A full charge takes approximately 4 hours.

**Charging:** When charging, an orange LED light will illuminate. The orange light will turn off when your speaker is fully charged.



4. Pairing Your Speaker with a Bluetooth Device



-Powering on your LifeJacket XL Speaker and Entering Pairing Mode

When you power on your LifeJacket XL speaker for the first time, it will automatically go into pairing mode. The LED status light will flash rapidly as your speaker searches for a Bluetooth audio source to pair with.

-Pairing Your Speaker with a Bluetooth Phone

Once your speaker is powered on and in pairing mode, go to the Bluetooth settings menu, make sure that Bluetooth is turned on, and then select "LifeJacket XL" to pair.



5. By downloading the "ALTEC CONNECT" app (for iOS and Android) you can personalize your LifeJacket XL speaker.

ALTEC CONNECT will allow you to:  
 -Enable the Stereo Plus Pairing setting  
 -Control Play/Pause/Skip/Volume/Mute  
 -Get over the air software updates  
 -Select EQ sound settings



-Using Near Field Communication to Pair Your Speaker with a Bluetooth Audio Source

With Near Field Communication (NFC), you can easily pair and connect your speaker to a compatible audio source. Once your speaker is powered on and in pairing mode, just hold your NFC enabled device directly against the wireless check in spot on your speaker.




Once you have successfully paired your speaker with a Bluetooth audio source, the LED status light will stop flashing rapidly, and begin shining steadily while remaining blue. In addition, your speaker will emit an audible tone to confirm that pairing was successful.

-Pairing Additional Bluetooth Devices to the LifeJacket XL Speaker


By holding down the Volume + and Volume - buttons simultaneously, your speaker will again go into pairing mode. The LED status light will flash rapidly, as your speaker searches for another Bluetooth audio source to pair with.

Note: Pairing mode times out in approximately three minutes.

6. You can also use the included 3.5mm Auxiliary Cable to connect audio devices through the AUX In port on your speaker



**Using the Mount:** The included mounting bracket allows you to attach your speaker to cylinder shaped surfaces such as the handle bars of a bicycle or ATV, or the rails on a yacht. This bracket comes unassembled. To use it, first attach the pieces as shown below. Next connect your speaker by screwing it into your speaker's tripod mount, and then attach the bracket to a suitable surface. Use the included wrench to help you loosen or tighten when necessary.



# JUST LISTEN.

# LIFEJACKET XL

## RUGGED BLUETOOTH SPEAKER



### Quick Start Guide

Item # IMW789



### Care & Maintenance

- Before using your speaker, inspect the ports and jacks to make sure that they are clear of dust and debris before charging or inserting an AUX Cable.
- Use a soft cloth to clean your speaker. Never use any harsh chemicals or detergents. Make sure your speaker is dry before using.
- When your speaker is not in use, it should be stored in a cool, dry place.
- Never tug or yank on the charging cable or AUX Cable while they are connected to your speaker. Connect and disconnect these cables as carefully as possible.
- If your speaker is exposed to salt water, wash it off with fresh water and then dry thoroughly before using.
- Give your ears a break. Do not listen to your speaker at high volumes for extended periods of time.
- Please recycle or dispose of your speaker properly based on the laws and rules of your municipality.



### Important Safety Precautions & Battery Information

1. Do not allow children or the infirm to play with your speaker without adult supervision.
2. Do not expose your speaker to excessive heat, flames or fire.
3. Always press all buttons carefully. Do not manhandle your speaker.
4. Do not use in extremely dry environments, as this can lead to static discharge during usage.
5. Do not expose your speaker to temperatures above 40°C. Keep out of direct sunlight.
6. Do not attempt to repair this product yourself. Contact a qualified service center if your speaker is in need of service.
7. Do not drop, puncture or expose your speaker to excessive trauma.
8. Your speaker is not intended for commercial use.
9. Do not place near objects that generate a strong magnetic field.
10. Unplug this device when not in use for long periods of time or during lightning storms.
11. The device is equipped with an integrated lithium-polymer battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.
12. The battery used in this device may present a risk of fire or chemical burn if mistreated.



**FLOATS IN WATER**  
WATERPROOF  
SANDPROOF  
EVERYTHING PROOF



**40 HOURS OF BATTERY**  
WITH BUILT IN  
PHONE CHARGER



**MULTI ROOM**  
PAIRING



**HANDS**  
**FREE**  
SPEAKERPHONE



**OMNI DIRECTIONAL**  
SURROUND  
SOUND

### Technical Support

For technical support issues please visit our website at [www.alteclansing.com](http://www.alteclansing.com). You can find manuals, software and FAQ's at the website. Can't find what you are looking for? Call 1-855-292-4087 to access our technical support information on the phone.

### Altec Lansing One Year Warranty Card

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

### What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

### To Obtain Warranty Service and Troubleshooting information:

Call 1-855-292-4087 or Visit our website at [www.alteclansing.com](http://www.alteclansing.com).

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the Product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaid.

**NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.**

**Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies. This product is manufactured, distributed and sold by SAKAR International, Inc. All other trademarks are the property of the respective owner, who has not sponsored, endorsed or approved this product.**

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/ TV technician for help.

