


What's in the box:



Complete the on-screen setup

Using your Alexa Voice Remote, follow the on-screen instructions to choose your language, select your Wi-Fi network and register your device.

Note: if your Wi-Fi network is password protected, have your Wi-Fi network password handy to connect your Fire TV Stick to the internet. If your network is hidden, select the Join Other Network tile from the list. If required, enter your network password using the on-screen keyboard.

Wi-Fi tips and troubleshooting

For best Wi-Fi performance, use the 5 GHz band on your wireless router if available.

If you see a lock icon, your Wi-Fi network requires a password, so make sure you have it available.

If you need help finding your Wi-Fi password, go to www.amazon.com.au/help/wifi.


Ensure your internet is working properly. Restarting your router and modem will solve most Wi-Fi network issues.

Do not place your wireless router or Fire TV Stick in a cabinet, as it may impact Wi-Fi signal strength.


Some Wi-Fi issues may be improved by connecting the included HDMI extender.

Connect your Amazon Fire TV Stick

Connect one end of the USB cable into your Fire TV Stick and the other into the power adaptor. Plug your Fire TV Stick into the HDMI port on your TV, then plug the power adaptor into a nearby electrical socket. Turn on your TV, then select the appropriate HDMI input.



Use the included HDMI extender to improve Wi-Fi and remote performance, or if you have trouble fitting your Fire TV Stick into an HDMI port on your TV.




Remote pairing

Having trouble with your remote? Unplug your Fire TV device from the power cord or adaptor, then plug it back in. Wait for the Home screen to appear. Remove and reinsert the remote's batteries. The remote should automatically pair with your device. If your remote isn't discovered, press and hold the Home button until the LED starts to rapidly flash amber. The LED will flash blue after the remote is successfully paired.


For more troubleshooting and information, go to www.amazon.com/devicesupport.

Power up your Alexa Voice Remote

1. Open the back of the remote and insert the included batteries.



2. After pairing your Alexa Voice Remote, follow the on-screen instructions to control the power and volume of your TV.



Get the most out of your Fire TV Stick

There's something always on

Watch free movies and TV shows with 7plus, 9Now, ABC iView, SBS On Demand, 10 Play and more. Get access to live sport and must-see shows. Easily download your favourite apps* like Netflix, Stan and Apple TV.

To learn more about your Fire TV Stick, visit www.amazon.com.au/firetv.

Press and ask Alexa

Press the Voice button on your included Alexa Voice Remote to easily find, launch and control content. Alexa can also play music, answer questions, read the news, check the weather and set alarms.

Things to try

"Alexa, show me comedy movies."

"Alexa, play top music hits."

"Alexa, rewind 30 seconds."

"Alexa, what's the weather?"

"Alexa, set a timer for 5 minutes."

To learn more about what Alexa can do, just ask

"Alexa, what can you do?"

* Certain services are subject to change or withdrawal at any time, may not be available in all areas or languages, and may require separate subscriptions and compatible equipment.