In the Box



A Closer Look



Charging



(red)= Charging

(off)= Charged

Powering On/ Bluetooth Pairing



True Wireless Stereo Mode

Parent speaker:
- Power on and connect to device via Bluetooth
- Press 'link' button for 4-5 seconds. Speaker will beep and light will turn green



= Parent Speaker Ready To Pair

Secondary speaker:
– Power on then quick press the 'link' button. Speaker will beep and light will turn green



= Secondary Speaker Ready To Pair

1-2 seconds later both speakers will beep and both green lights will be solid indicating speakers are paired to each other.

Just Ask/ Light Change Mode

To toggle between the different light modes: Multi color slow fade, White pulse to music, Multi color pulse to music, White slow fade, Solid Blue, Multi color change, Off.





Note: After Reset, First time Power on the unit, Around 20 seconds the Light will automatic change to off.

Controlling Music/Bluetooth Reset



PRESS
- Play/Pause
- Volume Up
- Volume Down

PRESS & HOLD
- Next Track
- Previous Track



PRESS & HOLD

Disconnect Bluetooth: Press & Hold for 5 seconds and device will beep.
Reset All Connections: Press & Hold for 10 seconds and device will beep twice.

Answering Calls



PRESS
- Volume Up
- Volume Down
- Answer Call/ End Call

PRESS & HOLD
- Ignore Call

Overall battery performance varies dependent upon use, settings and environmental conditions. For further information, please visit www.alteclansing.com

est. FIRST

FOLLOW US ON #myalteclansing