






# **1MORE EVO User Guide**











1. Why the headphones cannot be turned on? Check if your headphones have enough battery life. If not, please charge them for at least 30 minutes.

3) If headphones fail to connect, please put headphones into the correct slots in the charging case and

Why the headphones cannot connect to my celliphone, or take a long time to connect?
 Oheck that your headphones are in the searching mode (LED will flash white quickly).
 Make sure that your headphones are not connected to other devices, and that your device is not connected to other Bluetooth devices.

3. Why the headphones cannot play music after successfully connecting to my Android device? After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Media Audio" option is on.

4. Why there is no sound from the headphones while making phone calls after successfully connecting พระกรุง พระเกษ เอชาเอร After pairing successfully, on the Bluetooth menu of your device, tap the icon on the right of your device name and make sure the "Phone Audio" option is on.

5. Why the Bluetooth connection is not stable and causes some interruptions?
1) Try shortening the distance between your headphones and device. Avoid solid barriers in between.
2) Please keep away from strong interference sources, such as Wi-Fi and GPRS.
3) Please make sure the Bluetooth antenna of your device is not blocked.

6. Why some control functions do not match those in the manual while using third party music/video player Apps?
Your operating system and the third party music/video player apps may have different settings for the control functions. We recommend that you use the music/video player apps that your device has originally provided.

7. I turned the headphoens up to the maximum volume, but why the actual volume still sounds low? In different operating systems, especially some Android systems, the headphones and your device have separate volume control systems. Please adjust the volume controls on both the device and the headphones according to your preference.

8. Why are my headphones not able to connect to 1MORE MUSIC APP for the primary use? For Android users, please click "Allow all the time" to access to the location information of your device when entering 1MORE MUSIC APP. Or adjust this option in your settings for this app.

\* For more detailed product FAQs, please visit the product support section under www.1more.com

The SAR limit of USA (FCC) is 1.6 W/kg for head averaged over one gram of tissue. Device types EH902 (FCC ID: 2ASDIEH902R, FCC ID: 2ASDIEH902L) has also been tested with 0mm against this

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses

and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does caus harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of

This device complies with part 15 of the FCC rules. Operation is subject to the following two (1) this device may not cause harmful interference, and (2) this device must accept any interference

received, including interference that may cause undesired operation

Reorient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver.

authority to operate the equipment.

the following measures:

SAR limit.

click the pairing buttons for 3 times, the headphones will automatically pair to each other



1. Please read this instruction manual carefully and retain for future reference.
2. Please fully charge the battery before first use.
3. If the headphones have been unused for more than 3 months, we recommend that you charge them. This will improve battery capacity.
4. Only use charging cables and adapters that are FCC (Federal Communications Commission) approved.
5. In dry environments, static electricity may prime your ear. This is not related to the quality of the

5. In dry environments, static electricity may numb your ear. This is not related to the quality of the

product.

# Safety Caution Do not expose batteries or battery packs to excessive heat such as sunshine, fire or the like.

# All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.



The product SAR limit in europe is 2.0W/kg for head. The highest SAR value for this product when tested was 0.120W/kg for head(0mm). Declaration for EU Compliance Bluetooth:2402-2480(EIRP: Left 3.0dBm,right 4.5dBm)

Replacement of a battery with an incorrect type that can defeat a safeguard (such as catching fire, explosion, leakage of corrosive electrolyte etc); Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas. === The symbol indicates DC voltage.

